


1. With leak indicating patch facing outwards, wrap Safety Spray Shield around connection.
2. Overlap Shield and attach velcro patches together.
3. Arrange Shield so that leak patch is facing downwards and towards walkway for visual inspection (indicating styles)
4. When one end of matching drawcord in each hand, pull cord tightly to draw Shield down to pipe as much as possible.
5. Tie a square knot in each drawcord to securely hold in place.
6. Once installed properly, Shield is ready for service.

**SAFETY SPRAY SHIELD INSTALLATION INSTRUCTIONS**  
**(All Cloth)**



1. Wrap shield around fange (or expansion joint, valve, elbow, Tee, or other item for which shield was designed).
2. Make temporary connection of Velcro patches
3. Securely tie matching sets of draw strings with "square knot."
  - a. first holding one rope in each hand. Now cross left over right, and...
  - b. ...right over left. The knot has a square look to it.



**FAILURE TO USE SQUARE KNOT COULD RESULT IN RELEASE OF**

**DRAWSTRINGS UNDER PRESSURE.**