



RADOLID® NUT CAP

Installation Instructions

Rev. 092625

Page 1 of 1

1. To ensure a good fit, remove all foreign matter from area being covered by the Radolid® nut cap.
2. Pump Kleergel® synthetic corrosion protection gel 3 or 4 times to cover nut and bolt.
3. Brush Kleergel® over entire nut and bolt, apply more Kleergel® if needed to completely cover nut and bolt showing.
4. Push Radolid® nut cap over nut and bolt until the locking edge of the Radolid® nut cap locks under the nut. Radolid® nut cap sealing lip should fit flush with the surface of the flange.