

Before installing the Foreman Nite Cap you must remove the Pipe plug (Item # 10 shown below)

Note: Nite Caps are not pressure holding devices. However venting caps/pipe caps are standard features on most Nite Caps and are used to relieve the pipe of any naturally occurring pressure buildup.

Insert the Nite Cap into the end of the pipe, tighten down on the bolt, which in turn compresses the plates which expands the rubber creating a seal.



Before removing the Foreman Nite Cap from the pipe unscrew the vent cap/pipe cap to relieve the pipe of any pressure buildup.

Item No.	Description	No. Required
1	Outer Disc	1
2	Inner Disc	1
3	Hex Nut	1
4	Rubber Gasket	1
5	Steel and Fiber Washers	1
6	Hex-Head Bolt	1
7	Retaining Ring	1
8	Pipe Cap	1
9	Pipe Nipple	1
10	Pipe Plug	1

